

## Formaldehyde emission from wood based panels according to the gas analysis method EN 717-2



<b>Chamber</b>	4 L, stainless steel
<b>Sample specimen size</b>	3 x (400 x 50) mm
<b>Edge sealing</b>	Fully edge sealed using aluminum tape
<b>Temperature</b>	(60.0 ± 0.5) °C
<b>Air exchange</b>	60 L/hour
<b>Conditioning</b>	Hermetically sealed at ambient temperature °C for at least 1 day
<b>Test duration</b>	4 hours
<b>Limit of quantification</b>	0.2 mg/m <sup>2</sup> h